

PORTABILITY THAT PRINTS. SHARE SPECIAL MOMENTS ON THE GO.



With Epson PictureMate PM-520, you can now capture special moments on the go, connect wirelessly to the printer, print and share them instantly. Prints are borderless and up to 5 x 7" in size and with Epson Micro Piezo™ technology, they are both high-quality and long-lasting. The 2.7" LCD screen also makes picture selection and adjustment a breeze no matter where you go.



Borderless
Photo
Printing



Print
5760dpi



2.7" LCD
Screen



Wi-Fi Direct



Epson
Connect



Optional
Battery



Brilliant Prints Every Time

Epson Micro Piezo printhead delivers sharp, borderless prints of up to 5 x 7" quickly and effortlessly.

Wireless Connectivity

Wi-Fi and Wi-Fi Direct allow for wireless printing wherever you go. PM-520 supports Epson Connect features too.

Convenience in Every Way

Manage photos easily with a 2.7" LCD screen. PM-520 supports SD card, USB Flash Drives and PictBridge connectivity.

MODEL NUMBER	PM-520	
Printing		
Print Method	On-demand inkjet	
Nozzle Configuration	180 nozzles Black, 180 nozzles per colour (Cyan, Magenta, Yellow)	
Print Direction	Bi-directional printing, Uni-directional printing	
Maximum Resolution	5,760 x 1,440 dpi (with Variable-Sized Droplet Technology)	
Minimum Ink Droplet Volume	2 pl	
Print Speed ^{*1}	Approx. 36 sec per photo (Borderless)	
Photo Default - 10x15 cm/4x6" ^{*2}		
Paper Handling		
Paper Feed Method	Friction feed	
Paper Hold Capacity		
Input Capacity	50 sheets, A5 Plain paper (75 gsm)	
	20 sheets, Premium Glossy Photo Paper	
Output Capacity	20 sheets, A5 Plain Paper	
	20 sheets, Premium Glossy Photo Paper	
Paper Size	A5, A6, 9 x 13 cm (3.5 x 5 in), 10 x 15 cm (4 x 6 in), 13 x 18 cm (5 x 7 in), 16:9 wide size	
	Envelopes: #10, DL, C6	
Maximum Paper Size	136 x 420 mm	
Print Margin	0 mm top, left, right, bottom via custom settings in printer driver ^{*3}	
Interface		
USB	USB 2.0	
Network	Wi-Fi IEEE 802.11b/g/n, Wi-Fi Direct	
Mobile and Cloud Printing		
Epson Connect	Epson iPrint, Epson Email Print, Epson Remote Print Driver	
Other Mobile Solutions	Apple® AirPrint™, Google Cloud Print™, Mopria™ Print Service	
Control Panel		
LCD Screen	2.7" Colour LCD	
Card Slot		
Supported Memory Cards	SD, SDHC, SDXC, MiniSD (With Adapter), MiniSDHC (With Adapter), MicroSD (With Adapter), MicroSDHC (With Adapter), MicroSDXC (With Adapter)	
Supported File Formats	JPEG	
Printer Software		
Operating System Compatibility	Windows XP / Vista / 7 / 8 / 8.1 / 10	
	Mac OS X 10.6.8 or later	
Electrical Specifications		
Rated Voltage	AC 100-240V	
Rated Frequency	50 - 60 Hz	
Power Consumption		
Operating	12 W	
Standby	5.0 W (Not Charging), 24 W (Charging)	
Sleep	1.0 W (Not Charging), 22 W (Charging)	
Power off	0.2 W (Not Charging), 22 W (Charging)	
Noise Level		
PC Printing / Premium Glossy Photo Paper Best Photo	5.3 B(A), 40 dB(A)	
PC Printing / Plain Paper Default ^{*4}	5.3 B(A), 41 dB(A)	
Consumables		
Photo Ink Cartridge	Page Yield ^{*5} 160 Photo Prints	Order Code C13T372090
Maintenance Box	-	C13T295100
Options		
PictureMate Battery		Order Code C12C932941

Dimensions & Weight

Weight: 2.3 kg (5.1 lb)



^{*1} Photo print speed is calculated when printed on 10 x 15 cm Epson Premium Glossy Photo Paper with the default print settings. Print speed may vary depending on system configuration, print mode, document complexity, software, type of paper used and connectivity. Print speed does not include processing time on the host computer. The thumbnail image below shows the print pattern that was used to determine the print speed.



^{*2} When printed on Epson Premium Glossy Photo Paper

^{*3} Otherwise 3mm top, left, right, bottom. 10mm each side for A5.

^{*4} Default mode in accordance with ISO7779 for MFPS

^{*5} In accordance with ISO/IEC 29102. Actual yields will vary considerably for reasons including images printed, print settings, temperature and humidity. Yields may be lower when printing infrequently or predominantly with one ink colour. A variable amount of ink remains in the cartridges after the "replace cartridge" signal. Part of the ink from the first cartridges is used for priming the printer. Ink is used for both printing and print head maintenance. All inks are used for both black and colour printing.

© 2018 Epson Singapore Pte Ltd. All Rights Reserved. Reproduction in part or in whole, without the written permission from Epson, is strictly prohibited. EPSON and EXCEED YOUR VISION are registered trademarks of Seiko Epson Corporation. All other products names and other company names used herein are for identification purposes only and are the trademarks or registered trademarks of their respective owners. Epson disclaims any and all rights in those marks. Print samples shown are simulations only. Specifications and product availability are subject to change without notice and may vary between countries. Please check with local Epson offices for more information.

Apple, iPad and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android is a trademark of Google Inc.

Dealer's Stamp

Information correct at time of printing
Printed July 2018



For latest specifications, simply visit www.epson.com.sg/homeprinter or call **800 120 5564**.